

RUNNING YOUR SCOOTER

PRE-RIDE INSPECTION

⚠ WARNING

- **Failure to carry out a pre-ride inspection may result in serious personal injury or damage to the scooter.**

Check the scooter every day before starting up and carry out any necessary adjustments or repairs. The following checks will only take a few minutes and in the long run they will save time, money and possibly your life.

1. Oil level - Check the oil level and if necessary top it up (page 28).
2. Fuel level - refill fuel tank when necessary (page 25) Check for leaks in the tank.
3. Coolant level - Add liquid coolant when necessary. Check that there are no leaks (page 23 - 24).
4. Brakes (front and rear) - Check their efficiency and if necessary adjust play (page 18 - 22).
5. Tires front and rear- Check their condition and pressure (page 29 - 32).

6. Throttle - Check for smooth opening and full closing in all steering positions.
7. Lights and horn - Check that the (front and rear) lights, stop light, indicators, turn signals, and horn all work efficiently. Correct any fault before you ride. Contact your Honda dealer if there are any problems you cannot solve.