


Reverse Selector Knob

The reverse selector knob (1) is on the rear brake/parking brake lever.

When shifting the transmission into reverse, push the reverse selector knob in and squeeze the rear brake/parking brake lever.

The transmission will be shifted into reverse by depressing the gearshift pedal.




(1) Reverse selector knob

Neutral Indicator/Neutral Indicator Lamp

The FOUR TRAX 200SX is equipped with two indicators to show when the transmission is in neutral. This feature enables the rider to verify that the transmission is in neutral before starting the engine.

The neutral indicator lamp (1) is on the handlebar upper holder. When the ignition switch is turned ON, the lamp lights if the transmission is in neutral. If the lamp does not light, shift the transmission into neutral, whereupon the lamp will light.

The neutral indicator (2) is on the left crankcase cover, just behind the recoil starter. The indicator rotates as the gears are changed. When the indicator aligns with the N mark on the crankcase, the transmission is in neutral.



(1) Neutral indicator lamp (2) Neutral indicator