
## Refueling



Do not fill with fuel above the filler neck plate. **Fuel type:** Unleaded gasoline only **Recommended fuel octane number:** Pump Octane Number (PON) 86 or higher.

**Tank capacity:** 3.43 US gal (13.0 L)

Refueling and Fuel Guidelines P.13

## **Opening the Fuel Fill Cap**

Open the lock cover, insert the ignition key, and turn it clockwise to open the fuel fill cap.

## **Closing the Fuel Fill Cap**

- After refueling, align the fuel fill cap latch with the slot in the filler neck. Push the fuel fill cap into the filler neck until it snaps closed and locks.
- 2 Remove the ignition key and close the lock cover.
  - ► The ignition key cannot be removed if the fuel fill cap is not locked.

## AWARNING

Gasoline is highly flammable and explosive. You can be burned or seriously injured when handling fuel.

- Stop the engine, and keep heat, sparks, and flame away.
- Handle fuel only outdoors.
- Wipe up spills immediately.