


Instruments (Continued)

1 Setting of REV indicator:

You can change the setting of the REV indicator.

REV indicator blinks during setting.



- 1 To change the setting mode B, turn the ignition switch to the ON position while pressing **SEL** button until the initial animation ends. The display moves to the setting of "REV indicator blinking fastest RPM". At the same time, the numerical tachometer and the blinking bar segments show the current settings of the "REV indicator blinking fastest RPM".
 - Tachometer bar blinks only while setting of REV indicator.