

Display Setting


You can adjust the following settings.

- Clock setting
- Changing of speed and mileage unit


If the **SET** button was not pressed during the adjustment, and no buttons were pressed for about 30 seconds, the display will stop flashing automatically and the adjustment will be canceled.

1 Clock setting:

- Turn the ignition switch on.
- Press and hold the **SEL** and **SET** buttons until the hour digits start flashing.



- Press the **SEL** button until the desired hour is displayed.
 - ▶ Press and hold the **SEL** button to advance the hour fast.



- Press the **SET** button. The minute digits start flashing.

