

If You Have a Flat Tire

Emergency Front Wheel Removal/Installation

Refer to *Safety Precautions* on page 62 .


We recommend wheel removal be done only by your Honda dealer or another qualified mechanic. Do not attempt to remove the wheel on your own. Wheel removal requires mechanical skill and professional tools.

When removing and installing the wheel, be careful not to damage the sensor and pulser ring (Model equipped with ABS).

Removal

1. Park your motorcycle on a firm, level surface.

LEFT SIDE



- (1) fixing bolts
- (2) brake caliper assembly
- (3) fork leg
- (4) front axle bolt
- (5) axle pinch bolts

(cont'd)