

Tires — Check the air pressure and the tires for wear or damage. (pages 24—34)

Battery electrolyte — Check the level and add if necessary. (pages 170—172)

Throttle operation — Check throttle operation, cable routing and free play. (page 128)

Correct or replace if necessary.

Lighting — See if all lights operate properly.

Drive chain — Check condition of drive chain and measure the chain tension. Adjust if the chain tension is incorrect. Lubricate if it appears dry (page 144). Replace if it is badly worn or damaged.

---

Pneus — Vérifier la pression des pneus et leur état d'usure ou de dommage. (Pages 24—34)

Électrolyte de la batterie — Vérifier le niveau et ajouter, si nécessaire. (Pages 170—172)

Fonctionnement de la poignée des gaz — Vérifier le bon état de fonctionnement de la poignée des gaz, l'acheminement du câble, et la garde. (Page 128) Régler ou remplacer, si nécessaire.

Éclairage — S'assurer que tous les feux fonctionnent correctement.

Chaîne de transmission — Mesurer la tension et vérifier l'état de la chaîne. Ajuster la tension si elle est incorrecte. Lubrifier la chaîne si elle paraît sèche (Page 144). La remplacer si elle est usée ou endommagée.