

## STARTING THE ENGINE

**NOTE:** The electrical system is designed to prevent electric starting if the transmission is in gear, unless the clutch is disengaged. However, it is recommended that the transmission be placed in neutral before attempting to start the engine.

**WARNING:** Exhaust gases contain poisonous carbon monoxide. Never run the engine in a closed garage or confined area.

1. Make sure the transmission is in neutral and the fuel valve is ON.
2. Insert the key in the ignition switch and turn to ON. The neutral indicator (green) and oil pressure warning light (red) should go on.
3. Make sure the engine stop switch is in the run position.

---

## DEMARRAGE DU MOTEUR

**NOTE:** Le système électrique est conçu et construit de sorte qu'il empêche le démarrage électrique lorsque la transmission est engagée, à moins que l'embrayage est dégagé. Toutefois, il est recommandé que la transmission soit mise au point mort avant de tenter de démarrer le moteur.

**ATTENTION:** Les gaz d'échappement contiennent de l'oxyde de carbone poison. Ne jamais faire tourner le moteur dans un garage fermé ou dans un endroit clos.

1. S'assurer que la boîte de vitesses est au point-mort et que le robinet d'essence est sur ON (ouvert).
2. Insérer la clé dans l'interrupteur d'allumage et la tourner sur la position ON. Le témoin du point mort (vert) et l'indicateur lumineux de pression d'huile (rouge) seront allumés.
3. S'assurer que l'interrupteur d'arrêt du moteur soit mis sur la position RUN.