

HYDRAULIC BRAKE

Install the footpeg bracket assembly onto the frame. Install and tighten the footpeg bracket socket bolts to the specified torque.

TORQUE: 37 N·m (3.8 kgf·m, 28 lbf·ft)

Tighten the muffler guard bolt.
Adjust the rear brake light switch operation (page 4-27).

