

until compression is felt. With the engine against compression, pull the rope force fully to start.

If the engine does not start after several attempts, it is possible that the engine may have become flooded with excess fuel. To deflood the engine, turn the engine switch off, open the choke, hold the throttle fully open, and pull the recoil starter rope several times.

When the engine is deflooded, turn the engine switch on and repeat the normal starting procedure, but do not close the choke.


- * In cold weather, leave the choke lever closed during the first several minutes after the engine starts and then gradually open the choke as the engine warms up.

NOTE :

Do not race the engine during the warm up period. Revving a cold engine wastes fuel and increases engine wear.

WARNING :

Exhaust contains poisonous carbon monoxide gas. Never run the engine in a closed garage or in a closed garage or confined area.



⑤ Recoil starter