

## BREAK-IN PROCEDURE

During the first few days of riding, operate your new **ATC 90** so the engine neither pulls laboriously nor approaches maximum R. P. M. Avoid full throttle operation, and select your gear changes to spare the engine undue stress. Careful break-in procedure during initial operation will measurably extend the service life of the engine.

## RIDING

1. After the engine has been warmed up, the machine is ready for riding.
2. While the engine is idling, depress the gear change pedal to shift into low (1st) gear.
3. Increase engine speed by opening the throttle.
4. When speed increases close the throttle and shift to 2nd gear by depressing the gear change pedal.
5. This sequence is repeated to progressively shift to 3rd and top gear. The shifting pattern is illustrated on page 7.

## PARKING

When the **ATC 90** is parked, turn the main/headlight switch to "OFF" and fuel valve to "S".