


Battery Removal

CB1300/S

1. Remove the seat (page 79).
2. Remove the bolt (1).
3. Remove the engine control module (2).
4. Disconnect the negative (–) terminal lead (3) from the battery first, then disconnect the positive (+) terminal lead (4).
5. Pull out the battery (5) from the battery box.



- (1) Bolt
- (2) Engine control module
- (3) Negative (–) terminal lead
- (4) Positive (+) terminal lead
- (5) Battery