


● Helmet Holder

Two helmet holders ① are located at the three-quarter rear side of the seat. To hang helmets, raise the seat, hang helmets and push down the seat.

● Front Brake (Control) Lever

The brake lever ① (page 17) is located at the right handle bar grip. Application of the front brake is effected by squeezing the lever with a force proportional to the braking effort required.

NOTE: If lever free play is excessive, see page 55 for inspection and servicing information.



① Helmet holder