


Speedometer

Shows riding speed.

This shows your speed in kilometers per hour (km/h) or miles per hour (mph) depending on the type.

< E type only >

The unit of the indication depends on the unit which you set up (page 34).



(1) Speedometer