


Initial Display

When the ignition switch is turned ON, the multi-function display (1) and speedometer (2) will temporarily show all the modes and digital segments. Thereafter, the speedometer (2) will show from 290 km/h to 0 km/h (E type only: From 180 mph to 0 mph in mph) so that you can make sure the liquid crystal display is functioning properly.

(Except digital clock)

The unit “mph” and “mile” will be displayed only for E type.

Digital clock (3) and tripmeter (4) will reset if the battery is disconnected.



- (1) Multi-function display
- (2) Speedometer
- (3) Digital clock
- (4) Tripmeter
- (5) Fuel gauge