

Speedometer

Shows riding speed.


Odometer/Tripmeter

The odometer (2) shows accumulated mileage.

The tripmeter (3) shows mileage per trip.

Push the MODE button (4) to select the odometer and tripmeter.

To reset the tripmeter, push and hold the RESET button (5) for more than 2 seconds when the display is in the tripmeter.



- (1) Speedometer
- (2) Odometer
- (3) Tripmeter
- (4) MODE button
- (5) RESET button