

6. With the plug washers attached, thread the spark plugs in by hand to prevent cross-threading.
7. Tighten the spark plugs 1/2 turn with a spark plug wrench to compress the washer.
8. Reinstall the spark plug caps.

CAUTION:

- **The spark plug must be securely tightened. An improperly tightened plug can become very hot and possibly damage the engine.**
- **Never use a spark plug with an improper heat range.**

-
6. Monter les rondelles sur les bougies neuves et visser les bougies à la main afin d'éviter de visser en porte à faux.
 7. Serrer les bougies d'1/2 tour avec la clé à bougie de façon à comprimer la rondelle.
 8. Remonter les capuchons de bougie.

PRÉCAUTION:

- **La bougie d'allumage doit être bien serrée. Une bougie mal serrée peut devenir très chaude et endommager le moteur.**
- **Ne jamais utiliser de bougie d'allumage dont la gamme thermique ne convient pas.**