

ITEMS	FREQUENCY	WHICHEVER → COMES FIRST ↓ NOTE	ODOMETER READING [NOTE (1)]								Refer to pages	
			x 1,000 km	1	6	12	18	24	30	36		
			x 1,000 mi	0.6	4	8	12	16	20	24		
			MONTH		6	12	18	24	30	36		
DRIVE CHAIN			EVERY 1,000 km (600 mi) I, L								75	
DRIVE CHAIN SLIDER					I		I		I		81	
BRAKE FLUID		NOTE (3)			I	I	R		I	I	R	19
BRAKE PAD WEAR					I	I	I	I	I	I	I	92
BRAKE SYSTEM				I		I		I		I		19,91
* BRAKE LIGHT SWITCH						I		I		I		—
* HEADLIGHT AIM						I		I		I		—
CLUTCH SYSTEM				I	I	I	I	I	I	I	I	23
SIDE STAND						I		I		I		83
* SUSPENSION						I		I		I		82
* NUTS, BOLTS, FASTENERS				I		I		I		I		—
** WHEELS/ TYRES						I		I		I		—
** STEERING HEAD BEARINGS				I		I		I		I		—