


## PGM-FI Information

The PGM-FI indicator (1) goes on and the red information indicator (2) flashes when there is any abnormality in the PGM-FI (Programmed Fuel Injection) system.

The PGM-FI indicator should also go on for a few seconds and then go off when the ignition switch is turned ON and engine stop switch is at ○ (RUN).

If the PGM-FI indicator goes on and red information indicator flashes at any other time, reduce speed and take the motorcycle to your Honda dealer as soon as possible.



- (1) PGM-FI indicator
- (2) Information indicator