


ENGINE STOP BUTTON

The engine stop button (1) is next to the left handlebar grip.

Push the button in and hold it in until the engine stops completely.



(1) Engine stop button