

(Ref. No.) Description	Function
(7) Right turn signal indicator	Lights when the right turn signal operates.
(8) Coolant temperature gauge	Shows coolant temperature (see page 13).
(9) Maintenance indicator	Shows approaching specified maintenance interval for engine oil change (page 16).
(10) Tripmeter	Shows mileage per trip.
(11) Tripmeter reset knob	Resets tripmeter to zero (0) by pushing the knob.