
FINAL DRIVE OIL

(Refer to the maintenance precautions on page 61.)
Change the oil as specified in the maintenance schedule.

NOTE:

- Change the oil with the final drive at normal operating temperature and the motorcycle upright on firm, level ground to assure complete and rapid draining.
1. To drain the oil, remove the oil filler cap and drain plug.
 2. After the oil has completely drained, check that the sealing washer on the drain plug is in good condition and install the drain plug.
- Drain Plug Torque:**
20 N·m (2.0 kg-m, 14 ft-lb)
3. Fill the final drive with the recommended grade oil; approximately: 140 cm³ (4.7 US oz, 4.9 Imp oz). Make sure the final drive oil is filled up to the lower edge of the inspection hole with the recommended oil.
 4. Install the oil filler cap.

