

Search Lever:

You can find the station you wish by using the search lever. When the lever is pushed up, the frequency moves up, and when the lever is pushed down, it moves down.

If the lever is depressed once, the AM frequency display moves in 9 kHz steps and the FM frequency in 0.05 MHz steps.

- SEEK mode auto search:

Set the SEEK/SCAN select button to SEEK (page 60).

Release the search lever after the frequency display moves, and the next station is automatically tuned in. Repeat the above steps until the desired station is tuned in.

When the frequency display comes to either end, transition to the other end of the band takes place and continues in the same direction.

- SCAN mode auto search:

Set the SEEK/SCAN select button to SCAN (page 60).

The operation continues 10 seconds after the previous station was tuned in. To tune in the desired station, lightly push the search lever before the frequency display moves. The indicator "SCAN" will blink in the display while scanning stations.

