

Closing the Fuel Fill Cap

- 1 Install and tighten the fuel fill cap by turning it clockwise.
 - ▶ Make sure that the arrow marks on the cap and fuel tank are aligned.
- 2 Turn the key counterclockwise until it stops and remove the key.
- 3 Close the fuel tank lid.

WARNING

Gasoline is highly flammable and explosive. You can be burned or seriously injured when handling fuel.

- Stop the engine, and keep heat, sparks, and flame away.
- Handle fuel only outdoors.
- Wipe up spills immediately.