

## **FEATURES (Not required for operation)**


---

### **STEERING LOCK**

To lock the steering, turn the handlebars all the way to the left or right, turn the key to LOCK while pushing in. Remove the key.

#### **▲ WARNING**

- ***Do not turn the key to LOCK while riding the motorcycle; loss of vehicle control may result.***



### **SEAT**

To remove the seat, insert the ignition key into the lock and turn it clockwise.

#### **CAUTION:**

- ***Be sure to securely lock the seat after installing it.***

