

---

**Specified torque:**

**Axle bolt: 89 N·m (9.0 kgf-m, 65 lbf-ft)**

**Axle pinch bolt: 26 N·m (2.7 kgf-m, 20 lbf-ft)**

**▲ WARNING**

- *If a torque wrench was not used for installation, see your authorized Honda dealer as soon as possible to verify proper assembly. Improper assembly may lead to loss of braking capability.*
3. If the feeler gauge cannot be inserted easily, pull the left fork outward or push inward until the gauge can be inserted and tighten the axle pinch bolts with the gauge inserted.
  4. After tightening, remove the gauge. After installing the wheel, apply the brakes several times, then recheck both discs for caliper-holder-to-disc clearance. Do not operate the motorcycle without adequate clearance.

**▲ WARNING**

- *Failure to provide adequate disc-to-caliper-holder clearance may damage the brake discs and impair braking efficiency.*

(For model equipped with CBS/ABS/TCS)

**CAUTION:**

- *After installation, operate the brake lever and brake pedal and check the brake operation.*