STORAGE GUIDE

Extended storage, such as for winter, requires that you take certain steps to reduce the effects of deterioration from non-use of the motorcycle. In addition, necessary repairs should be made BEFORE storing the motorcycle; otherwise, these repairs may be forgotten by the time the motorcycle is removed from storage.

STORAGE

- 1. Change the engine oil and filter.
- 2. Make sure the cooling system is filled with a 50/50% antifreeze solution.
- Drain the fuel tank and carburetor into an approved petrol container. Spray the inside of the tank with an aerosol rust-inhibiting oil.
 - Reinstall the fuel cap on the tank.

NOTE:

 If storage will last more than one month, carburetor draining is very important, to assure proper performance after storage.

AWARNING

 Petrol is extremely flammable and is explosive under certain conditions. Perform this operation in a well-ventilated area with the engine stopped. Do not smoke or allow flames or sparks in the area where petrol is drained or stored and where the fuel tank is refueled.