


TRANSPORTING TIPS

The HONDA ST90 has been specially designed to fit in a limited carrying space for transporting to and from the riding area. The handlebar is easily moved to reduce the overall width of the ST90.

1. The handlebar ① is provided with a clamp which locks the handlebar mount to the fork bridge. Unlatching

the clamp releases the mount and permits the handlebar to be pivoted to conform with available storage space. Raise the clamp lever ②, and pivot the handlebar up to 90° in a counterclockwise direction. Do not allow the control cables to bind or stretch taut.



① Handlebar

② Clamp lever

