
The adjustment is made by turning the front brake adjusting nut ②.

Turning the nut in the direction ③


Turning the nut in the direction (A) will decrease the brake lever free play, and turning the nut in the direction (B) will increase the free play.

2. Minor adjustments can be made with the front brake cable adjuster on the front brake lever.

Loosen the lock nut (4) and turn the front brake cable adjuster (3). Turning the adjuster in direction (A) will decrease the brake lever free play and turning the adjuster in direction (B) will increase the free play.



2 Front brake adjusting nut



3 Front brake cable adjuster

4 Lock nut