

MAINTENANCE

MAINTENANCE SCHEDULE

- The maintenance intervals shown in the following schedule are based upon average riding, conditions, FOUR TRAX's subjected to severe use, or ridden in unusually dusty areas, require more frequent servicing. Perform the Pre-ride Inspection (page 26) at each scheduled maintenance period.

I: Inspect and Clean, Adjust, Lubricate or Replace, if necessary. C: Clean R: Replace A: Adjust			INITIAL SERVICE PERIOD (First week of operation)	REGULAR SERVICE PERIOD (Every 30 operating days)	Refer to page
*	FUEL LINE	YEAR I			47
*	FUEL STRAINER SCREEN	YEAR C			47
*	THROTTLE OPERATION		I	I	61
*	CARBURETOR CHOKE			I	-
	AIR CLEANER	NOTE 2		C	52
	SPARK PLUG			I	51
*	VALVE CLEARANCE		I	I	53-54
	ENGINE OIL		R	R	44
	ENGINE OIL FILTER SCREEN			C	45
*	ENGINE OIL CENTRIFUGE FILTER			C	46
*	CARBURETOR IDLE SPEED		I	I	48

- * SHOULD BE SERVICED BY AN AUTHORIZED HONDA DEALER, UNLESS THE OWNER HAS PROPER TOOLS AND IS MECHANICALLY QUALIFIED.
- ** IN THE INTEREST OF SAFETY, WE RECOMMEND THESE ITEMS BE SERVICED ONLY BY AN AUTHORIZED HONDA DEALER.