

## CONTENTS

|                                       | Page |
|---------------------------------------|------|
| FOURTRAX SAFETY .....                 | 1    |
| Special Safety Messages .....         | 1    |
| Warning Information.....              | 6    |
| <br>PARTS LOCATION AND OPERATION..... | 10   |
| Parts Location .....                  | 10   |
| Parts Operation.....                  | 13   |
| Power Controls .....                  | 13   |
| Lights .....                          | 20   |
| Gearshift Controls.....               | 23   |
| Brake Controls.....                   | 25   |
| Fuel Tank .....                       | 26   |
| Engine Oil .....                      | 28   |
| Additional Features .....             | 29   |
| <br>RIDING YOUR FOURTRAX.....         | 34   |
| Before Riding .....                   | 34   |
| Rider Preparation.....                | 34   |
| Vehicle Preparation .....             | 36   |
| Safe Riding Rules.....                | 44   |
| Riding .....                          | 56   |
| Starting the Engine .....             | 57   |
| Shifting Gears .....                  | 61   |
| Riding in Reverse.....                | 62   |
| Making Turns .....                    | 64   |
| Riding Up Hills .....                 | 67   |
| Riding Down Hills .....               | 74   |
| Crossing Slopes .....                 | 76   |
| Making Turns on Slopes.....           | 77   |
| Riding Over Obstacles .....           | 78   |
| Riding Through Water .....            | 79   |
| Parking.....                          | 80   |

(cont'd)