


# Instruments (Continued)

(VFR1200XD)



**TOTAL/TRIP button**

**FCD button**

**TOTAL/TRIP button &**

**FCD button** **↔P.20**

**Tachometer**

## NOTICE

Do not operate the engine in the tachometer red zone. Excessive engine speed can adversely affect engine life.


**Tachometer red zone**  
(excessive engine rpm range)

**Air temperature gauge (AIR)** **↔P.22**

**Coolant temperature gauge (↗)**  
**↔P.23**

**Speedometer**

**Fuel gauge** **↔P.21**



**Fuel mileage meter** **↔P.26**

**When the 1st (E) segment of the fuel gauge is flashed** **↔P.27**

**Odometer [TOTAL] & Tripmeter [TRIP A/B]** **↔P.23**

**Clock (12-hour display)**

**To set the clock** **↔P.24**

**Backlight brightness adjustment** **↔P.25**