


Checking the Engine Oil

1. If the engine is cold, idle the engine for 3 to 5 minutes.
2. Turn the ignition switch off, stop the engine and wait 2 to 3 minutes.
3. Place your motorcycle in an upright position on a firm, level surface.
4. Check that the oil level is between the upper and lower level marks in the oil inspection window.



Adding Engine Oil

If the engine oil is below or near the lower level mark, add the recommended engine oil.

➔ P. 57

1. Add the recommended oil until it reaches the upper level mark.
 - ▲ Place your motorcycle in an upright position on a firm, level surface when checking the oil level.
 - ▲ Do not overfill above the upper level mark.
 - ▲ Make sure no foreign objects enter the oil filler opening.
 - ▲ Wipe up any spills immediately.
2. Securely reinstall the oil fill cap.