

## INSTRUMENTS AND INDICATORS

The indicators are contained in the instrument panel. Their functions are described in the tables on the following pages.

- (1) Tachometer
- (2) Tachometer red zone
- (3) Anti-lock brake system (ABS) indicator (VFR-ABS)
- (4) High beam indicator
- (5) PGM-FI malfunction indicator lamp (MIL)
- (6) Right turn signal indicator
- (7) Right multi-function display
- (8) RESET button
- (9) HISS button
- (10) Immobilizer system (HISS) indicator
- (11) SELECT button
- (12) Left multi-function display
- (13) Left turn signal indicator
- (14) Low oil pressure indicator
- (15) Coolant temperature indicator
- (16) Neutral indicator

