

Installation:

1. Position the front wheel between the fork legs and insert the front axle shaft from the left side, through the left fork leg and wheel hub.
2. Tighten the front axle bolt to the specified torque:
59 N·m (6.0 kgf·m , 43 lbf·ft)
3. Tighten the axle pinch bolt on the right fork leg to specified torque:
22 N·m (2.2 kgf·m , 16 lbf·ft)
4. Install the right and left caliper assembly to the fork legs, tighten the fixing bolts and socket bolts to the specified torque:
31 N·m (3.2 kgf·m , 23 lbf·ft)
To avoid damaging the brake pads while installing the caliper assemblies, carefully fit both brake discs between the pads.
5. Temporarily tighten the axle pinch bolt on the left fork leg until lightly seat.
6. Operate the front brake and pump the fork several times.