

LEFT HANDLEBAR CONTROLS


Headlight Dimmer Switch (1)

Select HI for beam, LO for low beam.

Turn Signal Switch (2)

Move to L to signal a left turn, R to signal a right turn. Press to turn signal off.

〈Except AR type〉



- (1) Headlight dimmer switch
- (2) Turn signal switch


Horn Button (3)

Press the button to sound the horn.

Passing Light Control Switch (4)

〈AR type only〉

When this switch is pressed, the headlight flashes on to signal approaching cars or when passing.



- (3) Horn button
- (4) Passing light control switch