

INSTRUMENTS AND INDICATORS

The indicators are located within and ahead the speedometer.

Their functions are described in the table on the following pages.

- (1) Speedometer
- (2) Turn signal indicator
- (3) High beam indicator
- (4) Immobilizer system (HISS) indicator
- (5) PGM-FI multifunction indicator lamp (MIL)
- (6) High coolant temperature indicator
- (7) Odometer/Tripmeter display
- (8) Low oil pressure indicator
- (9) Neutral indicator
- (10) Odometer/Tripmeter select and reset button
- (11) Fuel indicator

