

INSTRUMENTS AND INDICATORS

The indicators are contained in the instrument panel. Their functions are described in the tables on the following pages.

- (1) Speedometer
- (2) Low oil pressure indicator
- (3) Tachometer
- (4) Tachometer red zone
- (5) Fuel reserve indicator
- (6) Side stand indicator
- (7) Neutral indicator
- (8) High beam indicator
- (9) Right turn signal indicator
- (10) Coolant temperature gauge
- (11) Tripmeter reset button and Odometer/Tripmeter select button
- (12) Odometer/Tripmeter display
- (13) Left turn signal indicator

