

ITEM	FREQUENCY	WHICHEVER → COMES FIRST ↓ NOTE	× 1,000 km × 1,000 mi MONTH	ODOMETER READING [NOTE (1)]								Refer to page
				1	6	12	18	24	30	36		
				0.6	4	8	12	16	20	24		
* FUEL LINE						I		I		I	—	
* THROTTLE OPERATION						I		I		I	88	
* CHOKE OPERATION						I		I		I	—	
* AIR CLEANER	NOTE (2)						I			I	—	
CRANKCASE BREATHER	NOTE (3)			C	C	C	C	C	C	C	84	
SPARK PLUGS				EVERY 24,000km (16,000mi) I, EVERY 48,000km (32,000mi) R							—	
* VALVE CLEARANCE								I			—	
ENGINE OIL			R			R		R		R	80	
ENGINE OIL FILTER			R			R		R		R	81	
* ENGINE IDLE SPEED			I	I	I	I	I	I	I	I	89	
RADIATOR COOLANT	NOTE (4)					I		I		R	32	
* COOLING SYSTEM						I		I		I	—	
* SECONDARY AIR SUPPLY SYSTEM	NOTE (5)					I		I		I	—	