

## INSTRUMENTS AND INDICATORS

The indicators are in the speedometer, above the headlight. Their functions are described in the table on the following page.

- (1) Speedometer
- (2) Tripmeter
- (3) High beam indicator light
- (4) Odometer
- (5) Tripmeter reset knob

