


ESSENTIAL INDIVIDUAL COMPONENTS

ENGINE STOP BUTTON

The engine stop button (1) is next to the left handlebar grip.

Push the button until the engine stops completely.



(1) Engine stop button