


FEATURES

(Not required for operation)

STEERING LOCK

The motorcycle has a steering lock (1) on the steering column under the headlight case. To lock the steering, turn the handlebar all the way to the left, insert the key into the cylinder, turn the key 180° clockwise. To unlock the steering, perform the locking sequence in the reverse order.




(1) Steering lock

TOOL BAG

A multi-purpose wrench (1) is in the tool bag (2) at the rear of the seat.

Some repairs, minor adjustments and parts replacement can be performed with this tool.

This owner's manual and other documents should be stored in the tool bag. When washing your motorcycle, be careful not to flood this area with water.



(1) Multi-purpose wrench

(2) Tool bag