

ITEM	FREQUENCY	NOTE	RUNNING-IN MAINT.	REGULAR MAINT. INTERVAL	Refer to
			First week of operation (about 200 mi, 350 km)	Every 30 operating days (about 100 mi, 1600 km)	
DRIVE CHAIN		NOTE 1	I, L	Every 10 operating days (about 300 mi, 500 km) I, L	67-71
DRIVE CHAIN SLIDER			I	I	68
BRAKE FLUID		NOTE 2		I	22
BRAKE SHOE/PAD WEAR				I	80-81
BRAKE SYSTEM			I	I	22-25
* BRAKE LIGHT SWITCH				I	82
* HEADLIGHT AIM				I	37, 83
CLUTCH SYSTEM			I	I	26-27
SIDE STAND				I	74
* SUSPENSION				I, L	72-73
* NUTS, BOLTS, FASTENERS			I	I	—
** WHEELS/TYRES			I	I	—
** STEERING HEAD BEARINGS			I	I	—

\* SHOULD BE SERVICED BY AN AUTHORIZED HONDA DEALER, UNLESS THE OWNER HAS PROPER TOOLS AND SERVICE DATA AND IS MECHANICALLY QUALIFIED. REFER TO THE OFFICIAL HONDA SERVICE MANUAL.

\*\* IN THE INTEREST OF SAFETY, WE RECOMMEND THESE ITEMS BE SERVICED ONLY BY AN AUTHORIZED HONDA DEALER.

NOTE: 1 Service more frequently when ridden in wet or dusty conditions.

2 Replace every 2 years. Replacement requires mechanical skill.