

## Gauges, Indicators & Displays

---

12	multi-function display	The display includes the following functions: <i>Display Check.</i>
	low oil pressure indicator/high coolant temperature indicator/HESD indicator	Lights the low oil pressure indicator and/or high coolant temperature indicator to notify that there is an abnormality in engine oil pressure and/or coolant temperature when the warning indicator lights (pages 30 , 31 ). Also, lights the HESD indicator to notify when there is an abnormality in the HESD (Honda Electronic Steering Damper) (page 32 ).
	speedometer	Shows riding speed in miles or kilometers per hour (page 34 ).
	digital clock	Shows hour and minute (page 43 ).
	coolant temperature meter	Shows coolant temperature (page 26 ). Fahrenheit (°F) or Centigrade (°C).