

Controls & Features

Horn Button



The horn is used to alert other motorists. To operate, push the horn button (3).

Control Button A

Control button A is used to:

- select the indication of the multi-function display (pages 33 , 35)
- to reset the tripmeter to zero (0) (page 36)
- to change the reset mode of tripmeter A and the fuel mileage meter (page 39)

- to change the speed, mileage and fuel mileage unit for the speedometer/odometer/tripmeter/fuel mileage meter (page 40)
- to change the temperature unit for the coolant temperature meter (page 41)
- to change the indication mode of the fuel mileage (page 42)
- to change the shift indicator and its display (pages 46 – 48)
- to set the digital clock (page 43)