
| Front Turn Signal Bulb


- 1. Remove the screw.
- 2. Fold the rearview mirror.



3. Remove the cover from the rearview mirror carefully in the procedure shown in the illustration.



- **4.** Turn the socket counterclockwise and pull it out.
- **5.** Slightly press the bulb in and turn it counterclockwise.



- **6.** Install a new bulb in the reverse order of removal.
 - ► Use only the amber bulb.
- **7.** Reinstall the cover and install the screw and tighten.

Torque: 0.7 lbf·ft (1.0 N·m, 0.1 kgf·m).