


Storage Equipment *(Continued)*


Luggage Tie-Down Hooks

The luggage tie-down hooks is located on the underside of the rear seat.

Luggage tie-down hooks



Luggage tie-down hooks



Never use the tie-down hooks to tow or lift the motorcycle.

Removing the Rear Seat ➔ P.81