

# Maintenance

Please read "Importance of Maintenance" and "Maintenance Fundamentals" carefully before attempting any maintenance. Refer to "Specifications" for service data.

An optional larger tool kit may be available.  
Check with your Honda dealer's parts department.

<b>Importance of Maintenance</b> .....	P. 58	<b>Side Stand</b> .....	P. 94
<b>Maintenance Schedule</b> .....	P. 60	<b>Drive Chain</b> .....	P. 95
<b>Maintenance Record</b> .....	P. 63	<b>Clutch</b> .....	P. 99
<b>Maintenance Fundamentals</b> .....	P. 64	<b>Throttle</b> .....	P. 102
<b>Removing &amp; Installing Body Components</b> ..	P. 78	<b>Crankcase Breather</b> .....	P. 103
Battery .....	P. 78	<b>Other Adjustments</b> .....	P. 104
Clip .....	P. 79	Adjusting the Headlight Aim .....	P. 104
Front Seat .....	P. 80	Adjusting the Brake Lever .....	P. 105
Rear Seat .....	P. 81	Adjusting the Front Suspension .....	P. 106
Left Side Cover .....	P. 82	Adjusting the Rear Suspension .....	P. 107
<b>Engine Oil</b> .....	P. 83		
<b>Air Cleaner</b> .....	P. 87		
<b>Coolant</b> .....	P. 89		
<b>Brakes</b> .....	P. 91		