

Engine

Number	135
Oil	72, 83
Oil Filter	85
Overheats	106
Starting	54
Stop Switch	50, 54, 127
Stopping	127
Will Not Start	105

Environment	134
--------------------------	-----

Equipment

Owner's Manual	58, 127
Tool Kit	57

F

Flooded Engine	54
-----------------------------	----

Fuel

Average Fuel Mileage Meter	22
Consumption Meter	23
Current Fuel Mileage Meter	22
Gauge	20
Recommended	56
Remaining	20
Reserve Fuel Consumption	24

Tank Capacity	56
Fuses	71, 123

G

Gasohol	141
Gasoline	56
Gear Position Indicator	20

H

Hazard Switch	50
Headlight Aim	101
Headlight Dimmer Switch	50
Helmet Holder	57
High Beam Indicator	45
Honda Contacts	145
Honda selectable torque control	53
Horn Button	50

I

Ignition Cut-off System

Banking Sensor	128
Side Stand	92

Ignition Key	126
Ignition Switch	51, 54, 127