

# Maintenance Schedule

Items	Frequency	Whichever Comes First ⇒	Initial Maint.	Regular Maint. Interval					Refer to page:
			mi	600	1,200	1,800	2,400		
		km	1,000	2,000	3,000	4,000			
Note	Month	1	6	12	18	24			
*	Fuel Line				I		I	—	
*	Throttle Operation				I		I	73	
	Air Cleaner	Note 1		C	C	C	C	68	
	Crankcase Breather			I	I	I	I	72	
	Spark Plug			I	I	I	I	79	
*	Valve Clearance		I	I	I	I	I	—	
	Engine Oil		R	R	R	R	R	62	
**	Engine Oil Strainer Screen				C		C	—	
**	Engine Oil Centrifugal Filter				C		C	—	
**	Engine Idle Speed		I	I	I	I	I	78	

\* Should be serviced by your dealer, unless the owner has the proper tools and service data and is mechanically qualified. Refer to the official Honda Service Manual (page 162 ).

\*\* In the interest of safety, we recommend these items be serviced only by your dealer.